# TP-Link Deco - X80-5G Set Up Instructions

1. Download the TP-Link Deco app

- When you open the box the first step will tell you to download the TP-Link Deco app (please note, at this stage you should NOT power on the Deco unit).
- You should use your preferred/regular mobile phone or tablet to download the TP-Link Deco App from either the Google Play or Apple App stores.
- Once installed, the Deco app will appear on your device as 'Deco'. Open the app to begin the set-up process.

Apple App Store - IOS

Google Play - Android

2. Create a TP-Link ID or tap "Already have an account" to log in (step 6)

3. Enter your email address

4. Set your password

Set Your Password

Password
•••••••••• 🚫

Confirm Password
•••••••••• 🚫

☑ I accept the Terms of Use and confirm that I have fully read and understood the Privacy Policy.

☐ Subscribe to the TP-Link newsletter and be the first to know about amazing deals, VIP giveaways, new products and so much more!

Next

---

5. Go to your email and a Activate your TP-Link ID by clicking the link that's been sent to you

✕

Activate Your TP-Link ID

An email has been sent to

Please follow the instructions in the email to activate your TP-Link ID within 1 hour.

Didn't receive email? Resend (51s)

Activated & Log In

Having problems?

**6. Log in to Deco using the email and password you've just set up.**

✕

Welcome to Deco

👤

🔒 •••••••••• 🚫

Forgot Password?

Log In

Don't have an account?

7. To start set up tap "Let's Begin"

≡

Paint Your Home in Wi-Fi

tp-link *tp-link* *tp-link*

LET'S BEGIN.

LOG OUT

8. Select the Deco unit you are setting up from the options below

<

Select Your Deco

🔍 Search for Deco model

Have more than one Deco model? ›

M Series

M3/M4

M5/M9 Plus

M1300

S Series

S4/S7

X Series

X20/X21

9. Search for the Deco X80-5G

<   X80-5G   ✕

X80-5G

<   X80-5G   •••

| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 0 |

q w e r t y u i o p

a s d f g h j k l

⇧ z x c v b n m ⌫

!#1 , English (AU) . 🔍

10. Tap "Use as a 4G/5G Router" as you are setting up a 5G Wireless device

11. Confirm that you have everything required to complete the set up including a Deco modem, a SIM Card, and a power cable.

12. Insert the SIM Card

✕

How do you want to use your product?

Use as a 4G/5G Router

Connect to the internet with my SIM card data.

Use as a Wi-Fi Router

Connect to the internet via an Ethernet cable.

How to use this product as both a 4G/5G...

‹

What you'll need

Find these in your Deco packaging. You'll only need one Deco for now. More can be set up later.

Note: There may already be a SIM card inserted into your Deco from your service provider.

Deco


Power Adapter

Nano SIM Card

→

‹

Insert the SIM Card

Push the SIM card into the slot until you hear a click.

Do not connect your Deco to a router/modem/ Ethernet outlet during the setup.

Note: If there's already a SIM card inserted, skip this step.

→

13. Position your Deco following the advice given on screen. You can use a mobile phone to find the best signal in your home to help with the set up.

Position your Deco

Place your Deco in an open area near a window and power outlet. Look for a location where it can receive a strong 4G signal. For best signal try windows on different sides of the house.

Position your Deco

Place your Deco in an open area near a window and power outlet. Look for a location where it can receive a strong 4G signal. For best signal try windows on different sides of the house.

Position your Deco

Place your Deco in an open area near a window and power outlet. Look for a location where it can receive a strong 4G signal. For best signal try windows on different sides of the house.

14. Power on Deco and wait until the LED pulses Blue, then tap next arrow→ to start pairing

15. Your phone will search for the Deco

16. Once found Deco app will request you to connect to the device

<

Power on Deco and wait until the LED pulses blue

● Solid Yellow: Deco is starting up, please wait.

● Pulsing Blue: Deco is ready for setup.

Why is my LED not pulsing blue?

→

×

Looking for Deco...

×

Connect to device?

Deco will use a temporary Wi-Fi network to connect to the device.

🛜 Deco_3668

Cancel

17. The app will confirm the Deco is now connected

✕

Looking for Deco...

Connected.

18. Select where the Deco is in your home. This helps to name the device in your app

✕

Where have you placed this Deco?

The location will be used as this Deco's name.

◉ Bedroom

○ Hallway

○ Kitchen

○ Living Room

○ Main Bedroom

○ Office

○ Study

○ Custom

Connect

19. The Deco will search for internet access

✕

Detecting internet connection type...

20. Create your own Wi-fi network by entering a network name and password. This will be what you use to connect to Wi-Fi

✕

Create Your Wi-Fi Network

This will be the name and password you'll use to access your network. Your password must be at least 8 characters.

🛜 Deco X80-5G

🔒 Password123

We recommend using a combination of letters, numbers, and symbols for your password.

Next

21. Once the network is set up the Deco app will assist you to connect to the Wi-Fi

✕

Connect to your Deco Wi-Fi

Connect your phone/tablet to the Deco's Wi-Fi to continue the setup.

Network Name
Deco X80-5G

Password
Password123

Copy Password

Connect

22. A screen will pop up to show you the Deco is connecting.

✕

Connecting to Deco X80-5G...

23. Then a screen will pop up to show you the app is testing the internet connection

Testing internet connection...

24. Setup of the X80-5G is complete. Tap DONE to finish

Your Deco network is now up

Your Deco is ready to use. Please connect all devices to the Deco network for better connections.

Done

Add another Deco